


CENTRAL OFFICE TO V-2006A CONNECTIONS (1 WAY PAGE)



Note: The suggestion provided may or may not be suitable for your intended application. Please consider this information carefully before incorporating it into your system design. Valcom disclaims any responsibility for accuracy or completeness.


	V-9940								V-2006A
SWITCH SETTING	1	2	3	4	5	6	7	8	SW6
	ON	OFF	OFF	OFF	OFF	OFF	OFF	ON	ON

VALCOM

5614 Hollins Road
Roanoke, VA 24019
540-563-2000
support@valcom.com

T9940>2006A

CENTRAL OFFICE TO V-2006AHF CONNECTIONS (TALKBACK PAGE)



Note: The suggestion provided may or may not be suitable for your intended application. Please consider this information carefully before incorporating it into your system design. Valcom disclaims any responsibility for accuracy or completeness.

	V-9940								V-2006A
SWITCH SETTING	1	2	3	4	5	6	7	8	SW6
	ON	OFF	OFF	OFF	OFF	OFF	ON	OFF	ON

VALCOM

5614 Hollins Road
Roanoke, VA 24019
540-563-2000
support@valcom.com

T9940>2006AHF